

Dog-walk Setup instructions: for both 12' and 8' dog walks



1. The shipment should contain three ramp boxes and a base box.

2. The unpacked dog walk should look like this picture. (See Part #s)



related parts packed in it: We use numbers for setting up references board). Squish both lock hinge handles in open position shown in 5-1. together to open the folded panel. Note: there are 4 knob screws inside the panel. They are part 14. Do not lose the base connection fixture. them!

Then turn part 1 upside down. Attach part 14 at each corner of

3. The base box has most of the base 4. Step 1: setup part 1 center panel (top 5. Straighten part 1 till it locks up 6. Next step is to connect part 8(shown in 6-1) to the top board, the center panel. Before connecting them, please make adjustment of height by pushing in the spring peg as orange arrow indicates, meanwhile, pulling top leg to extend the base to desired height. There is one peg on each side of each part 8.



7. Put base upside down, and insert round base leg into base connection fixtures at each corner of center board. Finish both sides then tighten the knob screws.

8. Connected part #8 to part #2. They should look like it shown in picture 8. Then, flip them back to up right position shown in picture 9. Make sure to adjust each base #8 straight up as a right angle to board #2.

10. Next step is to connect part #7 instant height adjustable center support bar to the back of #2. It requires use of part #12 like it shows in picture 10.

11. There are two screw holes on the back of center #3 to #2. This step is easy. Just part #2. use #12 connect #7 to #2. Adjust the height of #7 by pushing the white metal pole to stretch or condense telescoping pieces for weight support.



12. Next to connect ramps #1 and remove handle straps from the ramps dog walk should look like and open them. Use Part # 10 to connect ramps to the center board.

13. After connecting ramps to center board, the shown in picture 13



14.Install part # 6 under the ramps just like it was done in the installation of part #7 to the center board. Use part #10 on each part #6 for each ramp. Make adjustment of weight distribution.

15. The rest of steps are straight and easy. Just follow your own imagination to assemble them together. Connect reinforcement support rods, #4 to the base. The purpose of these rods is for insuring the equipment's sturdy ability to undertake the impact from high speed moving dogs.

16. There are 4 pairs of part #4s. They are of telescopes type in the same size. Connect outer rod ends to the bottom of the bases. and connect inner rod ends to the back of center board #2 and ramp #1, #3. Remove the cotter pins and washer rings and connect #4 to the base #8 one by one.

17. Correct connection should look like shown in picture 17. There is a twisting knob on each telescoping rod #4 to let them slide or tighten up. Loosen the knob first before pulling out the inner rod to connect the other ends to the back of board and ramps.

Designer and Maker: PRI Questions: prii@att.net

18. There are 4 #11 parts, the rods for connect part #4 to back of the board and ramps. There are 2 pair of holes on the side of center board and one on each side of ramps. (see the arrow) Remove cotter pins and connect #4 inner rod ends to back of the board and ramps.

Copy Right reserved

contracted or extended. The setup is finished. Finished setup should look like it shown in picture 19. The corner picture shows the usage of ramp end sturdy bar #9. If customers want to install them. use 2 #10s for each end. Note it is better to use old carpet to cover exposed metal pieces. Customers please beware of the risk of use. Small sized dog-walks do not use.